


SPARE PARTS PRICE LISTS

TUBULAR LB

Spare parts can be obtained only by ordering the relevant kit. Spare parts cannot be ordered individually. In order to locate the relevant spare part, please check the corresponding part and part number at the drawing at the last page. When ordering spare parts (kits) please mention the corresponding catalog number (Cat. No.).

Quantity	Part Number	Description	Cat. No.
	-	Seals and Screws Kit	07210015
1	7	O-ring	04510078
1	3	O-ring	04510193
1	15	O-ring	04510297
1	5	Screw	05010405
1	6	Screw	05010316
	-	Self Adaptive Sensor Kit	07220056
1	2	Self Adaptive Sensor	08002110
1	3	O-ring	04510193
	-	Solenoid BS-Housing Kit/ Solenoid BS-Housing Kit for USA	07231008/ 07231009
1	9	Solenoid valve's body	07502019
1	12	Filter	08530013
1	13	Nipple	07025015/ 07025078
	-	Solenoid Valve Kit	07230017
1	11	Solenoid valve	07500025
1	10	Diaphragm	04500001
	10	Diaphragm	04500001
	14	IP 67 Battery box	06530020
	14	Battery box	06530008

Tubular LB



Y.STERN ENGINEERING LTD.